



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3747	Slider Retainer Screw	6794	Bail Trip Lever
0071	Rotor Nut	3848	Bail Spring Guide (A)	6795	Counterbalance Cover
0452	Drag Spring Washer	3849	Bail Spring Guide (B)	7289	Push Button Collar
0540	Multi-Purpose Screw	3853	Anti-Reverse Lock Out	7290	Push Button
0574	Drag Washer "C" (cloth)	3854	Anti-Reverse Lock Out Spring	7295	Ball Bearing
0579	Eared Washer "B"	3855	Lock Out Spring Holder	7297	Anti-Reverse Cam
0584	Hold Click Spring	3856	Anti-Reverse Pawl	7298	Anti-Reverse Lever
0642	Side Cover Screw	3857	Anti-Reverse Pawl Spring	7300	Oscillating Slider Retainer
0779	Multi-Purpose Screw	4049	Large Hole Washer	7301	Oscillating Slider Inner
0787	Nut Lock Screw	4096	Drag Shaft	7302	Oscillating Slider
0792	Bearing Retainer Screw	4097	Pressure Screw	7303	Oscillating Gear
0848	Small Hole Washer	4099	Drag Knob Screw	7304	Oscillating Gear Bushing
1008	Handle Lock Washer	4111	Pinion Gear	7305	Drag Spring
1891	Bail Spring Cover Screw	4112	Drive Gear	7306	Drag Knob
2257	Drag Washer "H" (blue)	4367	Line Roller Screw	7307	Handle Assembly
2283	Anti-Reverse Pawl Screw	4568	Bail Arm	7309	Spool Assembly
2419	Handle Screw Cap	5625	Line Roller Spacer	7310	Main Shaft
2852	Handle Screw Lock	5628	Line Roller Collar	7311	Bail Assembly
3359	Line Roller Washer	5629	Line Roller Bushing	7337	Ball Bearing
3397	Bail Spring	5630	Line Roller	7339	Rotor
3402	Cover Screw	5690	Anti-Reverse Lever Screw	7340	Body Set
3471	Anti-Reverse Cam Spring	5996	Locking Spring		
3744	Drag Click	6787	Bail Spring Cover		